

us15Series



USER MANUAL

ZKTeco

CONTENT

1	USER MANAGEMENT	5
1.1	New User	6
1.2	All Users	13
1.3	Single Line	14
2	USER ROLE	15
3	COMMUNICATION	17
3.1	Ethernet	18
3.2	Serial Communication	18
3.3	PC Connection	19
3.4	Wireless Network	20
3.5	Cloud Server Settings	21
3.6	Wiegand Setup	23
4	SYSTEM	25
4.1	Date Time	26
4.2	Attendance	26
4.3	Fingerprint	29
4.4	Reset	31
4.5	USB Upgrade	31
5	PERSONALIZE	32
5.1	User Interface	33
5.2	Voice	36
5.3	Bell Schedules	37
5.4	Punch State Options	41
5.5	Shortcut Key Mapping	42
5.6	Manual Add Log	47

CONTENT

6	DATA MANAGEMENT	49
6.1	Delete Data	50
6.2	Backup Data	51
6.3	Restore Data	52
7	ACCESS CONTROL	54
7.1	Time Schedule	55
7.2	Access Group	55
8	USB MANAGER	59
8.1	Download	60
8.2	Upload	61
8.3	Download Options	61
9	ATTENDANCE SEARCH	63
10	SHORT MESSAGE	66
10.1	New Message	67
10.2	Public Messages	69
10.3	Personal messages	69
10.4	Draft Messages	69
10.5	Message Options	70
11	WORK CODE	71
11.1	New Work Code	72
11.2	ALL WORK CODES	73
11.3	SET WORK CODE	73

CONTENT

12	JOB CODE	75
12.1	New Job Code	76
12.2	All Job Codes	77
12.2	All Job Codes	80
12.3	Job Code Options	83
12.4	Job Group Option Menu Operation	85
13	TIP CODE	88
13.1	Tip code settings	89
13.2	Tip code	90
14	AUTOTEST	94
14.1	All Test	95
14.2	Test LCD	95
14.3	Test Voice	97
14.4	Test Keyboard	97
14.5	Test Fingerprint Sensor	97
14.6	Test Clock RTC	97
15	SYSTEM INFORMATION	98
15.1	Device Capacity	99
15.2	Device Info	99
15.3	Firmware Info	100



USER MANAGEMENT



Go to menu and select **User Management**.



1.1 NEW USER

Select **New User**.

User ID	1
Name	
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	0
Badge Number	

Select **User ID** and press **OK**.

Enter the **User ID** by using the keypad and press **OK**.

User ID	1
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	0
Badge Number	
Password	

Select **User Role** and press **OK**.

Click on **Registrar** and press **OK**.

New User	
User ID	2
Name	
User Role	Registrar
Verification Mode	Password/Badge
Badge Number	
Password	

A user with "Registrar" is able to "Add", "Delete" and "Edit" standard users to the device.

He is also able to view "Standard Attendance Data" for existing users on the clock.

User Role
☐ Normal User
☒ Super Admin

Select **Super Admin** and press **OK**.

The super administrator has rights to all the menu functions.

New User	
User ID	1
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	0
Badge Number	
Password	

Select **Verification Mode** and press **OK**.

Verification mode is basically used to verify the user.

Verification Mode
☒ Apply Group Mode
☐ Password/Fingerprint/Badge
☐ Fingerprint only
☐ User ID only
☐ Password


Select **Apply Group Mode** and press **OK**. By pressing the apply group mode the user can verify himself with all the options that are available in verification mode.

Verification Mode
☐ Apply Group Mode
☒ Password/Fingerprint/Badge
☐ Fingerprint only
☐ User ID only
☐ Password
☐ Badge only


By clicking the option above the user can verify himself either with his/her **Fingerprint/Password or Badge**.

Verification Mode
☒ Apply Group Mode
☐ Password/Fingerprint/Badge
☐ Fingerprint only
☐ User ID only
☐ Password
☐ Badge only

Select **Apply Group Mode** and press **OK**.




When you select the option from above the user needs all three things to verify himself or it won't verify.



When you select the option above the user needs his/her fingerprint and either badge or user id to verify himself.

When there is "/" sign it means you can use either option to verify.



To enroll the fingerprint for the new user select **fingerprint** and select **OK**.



Place your finger on the fingerprint sensor properly.




Place the same finger on the fingerprint sensor for the second time.




After that, you can again place the same finger on the fingerprint sensor.




Enrollment succeeds. If the enrollment fails, the system will display a prompt message and return to the [Enroll Fingerprint] interface. In this case, you need to repeat the operations of step 2




After the fingerprint is enrolled successfully the fingerprint will be shown as 1 as above which means one fingerprint is enrolled.



Select **Badge Number** and press **OK**.




When you select the badge number it will tell you to swipe the badge/rfid card to enroll.




When you swipe the badge number the badge number will be displayed as above.

Here I swiped badge number 4261414 and that number is enrolled for that user.




Select **Password** and press **OK**.



Screen titled "Password". It displays "Please Input" above a text entry field. At the bottom are two buttons: "Confirm (OK)" and "Cancel (ESC)".


Here you can input the password by using the keypad to enroll.



Screen titled "New User". It shows a list of fields for user enrollment:


User ID	1
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	1
Badge Number	4281414
Password	*****

Once you have entered the password, the above image will be displayed for that user with his/her fingerprint, the badge number, and password that needs to be entered.



Screen titled "New User". It shows the same enrollment fields as before, but the "Lockout Override" field at the bottom is highlighted in yellow and set to "Disable".

Select **Lockout Override** and select **OK**




Screen titled "Lockout Override". It has two radio button options: "Disable" (which is selected and highlighted in yellow) and "Enable".

Select lockout override as **Disable**.



Screen showing an error message. On the left is a large red "X" icon. On the right, the text reads: "User ID : 1", "Verify : Fingerprint", "Error! Invalid time period", and "Failed to verify." The top status bar shows the date and time: "01/09/18 09:46 AM".

A user punches in off the activate schedules, the device will notify the user by "Error! Invalid time period Failed to verify."



Screen titled "Lockout Override". It has two radio button options: "Disable" and "Enable" (which is selected and highlighted in yellow).

Select lockout override as **Enable**.

USER MANAGEMENT

New User	
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	1
Badge Number	
Password	
Lockout Override	Enable

When you enable this function the above image will be displayed.

01/09/18 09:48 AM

User ID : 1

Name : May

Verify : Fingerprint

Successfully Verified

A user punches in off the activate schedules, the device will notify the user by "Successfully Verified." as shown above.

New User	
Fingerprint	1
Badge Number	
Password	
Lockout Override	Enable
Access Control Role	
Duplicate Punch Period(s)	0

Select **Access Control Role** and press **OK**.

Access Control	
Access Group	1
Verification Mode	Apply Group Mode
Duress Fingerprint	Undefined
Apply Group Time Period	☒ ON

Select **Access Group** and press **OK**.

Access Group

Please Input (1 - 99)

Confirm (OK)

Cancel (ESC)

You can change the number for that group in the input section above using the keypad.


Access Control	
Access Group	1
Verification Mode	Apply Group Mode
Duress Fingerprint	Undefined
Apply Group Time Period	☒ ON

Select verification mode and press **OK**


USER MANAGEMENT




In verification mode, you can select apply group mode which will select all the methods of verification as shown above.




Select duress fingerprint and press **OK**.



Press ◀▶ to select enrolled fingerprint and press **OK**.



Press ▼ to select Apply Group Time Period, press **OK** to select whether the user uses his/her group's default time zone.



When **OFF** is selected, Press ▼ to select Time period 1.



Similarly, you can choose time period 2 and press **OK**.

New User	
Fingerprint	0
Badge Number	
Password	
Lockout Override	Disable
Access Control Role	
Duplicate Punch Period(s)	0

Select duplicate punch period and press **OK**.

Duplicate Punch Period(s)	
☒ Disabled	
☐ 10	
☐ 20	
☐ 30	
☐ 40	
☐ User Defined	

Here you can **Disabled** or select the punch period you want.

User Mgt	
New User	
All Users	
Display Style	

1.2 ALL USERS

Select **All users** and press **OK**.

All Users	
1	

Press to select "All User and press" **OK**.

User : 1	
Edit	
Delete	

Press **OK** to enter User Info interface. Here you can **Edit** the user information.

Edit : 1	
User ID	1
User Role	Normal User
Verification Mode	Apply Group Mode
Fingerprint	1
Badge Number	4261414
Password	xxxxxx

The User ID cannot be modified, and the other operations are similar to those performed to add a user.




If you want to delete the user select **Delete** as shown above and press **OK** and the user will get deleted.




1.3 SINGLE LINE


Press ▼ to select display style and press **OK** to return.



Single Line



Multiple line



Mixed Line



USER ROLE



Select **User Role** and press **OK**.



Click on **Registrar** and press **OK**

You are also able to view "Standard Attendance Data" for existing users on the clock



Here you can **Enable the defined Role** for user by turning it ON.



Select **Define User Role** and press **OK**.



Press **▼** and **OK** to select the rights. Press **ESC** to exit.



COMMUNICATION



Go to menu and select "COMM" and press **OK**



3.1 ETHERNET

Select **Ethernet** and press **OK**




IP Address: IP is 192.168.1.201 by default. You can modify it if it is necessary. But it cannot be the same with that of PC.



3.2 SERIAL COMMUNICATION


Select **Serial Comm** and press **OK**



Select "Serial Port" and press **OK**.




RS232: Whether to use RS232 to communicate or not. Select **YES** if RS232 is to be used.



Select **Serial Port** as no using if you do not want to use the port.



Baudrate: Used for communication with PC.




There are five options: 9600, 19200, 38400, 57600 and 115200. If the communication speed is high, RS232 is recommended. If the communication speed is low, RS 485 is recommended




3.3 PC CONNECTION


Select **PC connection** and press **OK**.




Select **Comm Key** and press **OK**




Enter a password in the input box using the keypad as shown above and to select confirm **OK** and press **OK**.




Select **Device ID** and press **OK**.



Here you can input the number for this device by using the keypad and hit press confirm **OK**.




Here the **Use SSH** is **OFF**



When you turn **ON** the "SSH" function the device will restart automatically as shown above.

When this function is enabled you cannot "Telnet" into the clock as it will disable that function.



3.4 WIRELESS NETWORK


Click on **Wireless Network** and press **OK**



When you select the wireless network option the following window will appear in which as a default **WIFI** would be **OFF**.



You can turn **ON** the wireless network and the networks available in the range would be displayed as above.



You can select any wireless network you wish to connect and you can upload the password via "USB" or by using the keypad on the clock. Once you upload the password the following network will get connected.

See NOTE below



Once the password is uploaded successfully the above image will be displayed as "Upload is done"



3.5 CLOUD SERVER SETTINGS

Click on "Cloud Server Settings" and press **OK**



Select **Server mode** as "PUSH" as shown above.

It refers to your push server address.


NOTE: The new filename for uploading Wi-Fi password or URL Webserver: updataoptions2.cfg

Inside this file you can either use: WirelessKey= [for uploading Wi-Fi password] or ICLOCKSVRURL= [for uploading webserver URL]


The clock won't accept saving those two configurations under the same filename. Our suggestion would be to save one separate file for Wi-Fi and one for URL.



Here the URL Mode is **OFF**.




You can turn the "URL" mode **ON** by pressing the **M/←** button on the clock.




Once the "URL Mode" is **ON** you can upload the server address with "USB".


See NOTE below




Here the server address is the IP address of the webserver.



Here you can change server port of the webserver by using the keypad and pressing confirm **OK**.



Select **Server port**. It is as port which is used by the webserver.




Here you can change server port of the webserver by using the keypad and pressing confirm **OK**.


NOTE: The new filename for uploading Wi-Fi password or URL Webserver: updataoptions2.cfg

Inside this file you can either use: WirelessKey= [for uploading Wi-Fi password] or ICLOCKSVRURL= [for uploading webserver URL]

The clock won't accept saving those two configurations under the same filename. Our suggestion would be to save one separate file for Wi-Fi and one for URL.



Here you can select the proxy server to be **Enabled** or not. If it is off as above the proxy server will be disabled.




When you enable the proxy function, set the IP address and port number of the proxy server. This option indicates whether or not to use a proxy IP address. You may choose to enter the proxy IP address or the server address for Internet access, whichever you like.




3.6 WIEGAND SETUP


Click on **Wiegand Setup** and press **OK**




Click on **Card format detect automatically** and press "OK".
(This function is available only for standard RFID and HID proximity Cards)



Here you can swipe the multiple types of cards with different Wiegand formats.




After you swipe multiple cards all the cards with different Wiegand formats will be displayed as above.



Here you can select the Wiegand format of the card you wish to choose to register.

If you select **Cancel** that Wiegand format would not be selected.



To select the particular Wiegand card format select that format and press **OK** as shown above..



SYSTEM



Select "System" and press **OK**



4.1 DATE TIME

Select **Date Time** and press **OK**.




Press **◀▶** and **OK** to select items. When the setting is completed, press **OK** to save the setting and exit.




4.2 ATTENDANCE


Select **Attendance** and press **OK**.




If you want to display the user photo you can select ON




If you don't want the user photo to be displayed select OFF as above.




When the available space is insufficient to store the specified number of attendance records, the FFR terminal will automatically generate an alarm. (Value scope: 1-99)




You can change the value for attendance log alert from the image above.




Select **Cyclic Delete ATT Data**. It specifies the maximum number of attendance records that can be deleted at a time when the number of attendance records reaches the upper limit.




This function can be disabled; otherwise, the value ranges from 1 to 999




The screen delay specifies the time for displaying the authentication result.



The value ranges from 1s to 9s.



You can select the expiration rule as OFF if you don't want to retain the user information or to save attendance records.



You can select one of the three conditions:

- Retaining user information and not saving attendance records;
- Retaining user information and saving attendance records;
- Deleting user information




Click on the **Verification Result Font Customization** option from above and press **ON** to change the Font Size.



Here the default the font size would we be set to "Medium".




Here you can change the Font size from **Medium** to **Large** or **Maximum**.



Select **Verification Result Font Color** from above and press **OK**



Here you can change the color of the font to a different color you wish to apply.



4.3 FINGERPRINT

Select **Fingerprint** option and click **OK**.



Here select **1:1 Match Threshold**. The value is similar to the ID+fingerprint verification and the enrolled template.



You can change the value from the image above. The default will be selected as 15.



Here select **1:N Match Threshold**. The value is the similar to verification and the enrolled template.



You can change the value from the image above. The default will be set to 35




Select **FP sensor Sensitivity** and press **OK**. It is used to set the sensitivity of fingerprint collection.




The default value Medium is recommended. You can set the sensitivity of fingerprint collection to High when the response to finger scan lags in a dry environment. When the usage environment is humid, you can set the sensitivity of fingerprint collection to Low if the fingerprint is difficult to identify.




This parameter is used to set the retry times in the event of failure of 1:1 verification or password verification due to an absence of fingerprint enrollment or improper finger placement, so as to avoid repetitive operations.




You can change the retry times from the image above. The value ranges from 1 to 6.



Here you can select the **Fingerprint Image** to be shown. If you select this option the display of the fingerprint image on the screen will be shown.



Here you can change the fingerprint image to be shown while enrolling or to match and never



4.4 RESET

Select **Reset**.



When you select **Cancel** it will go back to the previous menu.
If you select **OK** it will reset the setting and restart the clock.



4.5 USB UPGRADE

Select **USB Upgrade**.



If the USB is not readable or properly inserted the image above will be displayed and you will not be able to upgrade.



If the USB is readable or properly inserted the image above will be displayed and you will be able to upgrade.



PERSONALIZE




Select **Personalize** and press **OK**.



5.1 USER INTERFACE

Select **User Interface** and press **OK**.




Select **Wallpaper** and press **OK**.




If you select the wallpaper, the different wallpapers will be displayed as shown above and you can select from any of the wallpaper you want to be displayed.




Select **Language** and press **OK**.



Here you can select the language you wish to display on the clock. The options are English and Espanol (Spanish).




To prevent hostile power-off, select whether to lock power-off or not.
 "disable": the power is off 3 seconds after pressing power-off.



"Enable": it is ineffective after pressing power-off



The device will display the main interface automatically when no operation is performed on a menu within the menu timeout time



This function can be disabled; otherwise, the value ranges from 60s to 99999s.



The advertisement picture is displayed when no operation is performed on the main interface within the waiting time.



This function can be disabled; otherwise, the value ranges from 15s to 999s



This parameter is used to set the picture cycle interval



This parameter can be either disabled or ranges from 30 s to 999s.




This parameter is used to set the picture cycle interval



This parameter can be either disabled or ranges from 30 s to 999s.



This parameter is used to specify a period after which the device is put in sleep mode if no operation is performed within this period. You can wake up the device from sleep by pressing any key or touching the screen.



Numerical range in 30 minutes, the factory default for 30 minutes.



This is to set where and how the clock and status key are displayed on the main screen.




Here is the "Style 1". If you want this style press **Set** and **OK**. And if you don't want this style simply press back.



Here is the "Style 2". If you want this style press **Set** and **OK**. And if you don't want this style simply to press back.



Here is the "Style 3". If you want this style press **Set** and **OK**. And if you don't want this style simply press back




5.2 VOICE


Select **Voice** and press **OK**.



Voice prompt: This parameter is used to set whether to play voice prompts during the operation of the FFR terminal. Select **ON** to enable the voice prompt, and select **OFF** to mute.




Keyboard prompt: This parameter is used to set whether to generate beep sound in response to every keyboard touch. Select **ON** to enable the beep sound, and select **OFF** to mute



5.3 BELL SCHEDULES

Select "Bell Schedules" and press **OK**.



Click on **New bell schedule**.




Click on bell status. It is whether you want the bell to enable. If you turn **OFF** it will disable the bell.



If you turn **ON** it will enable the bell.




The bell rings automatically when it is the specified time.




You can change the timings for the bell to ring using the keypad and then press confirm **OK**.

Here the bell is scheduled at 12.24PM.




The Repeat function specifies whether to repeat the ringtone



You can select any day of the week to repeat the ringtone. If you don't want the ringtone to be repeated set to never.




Select **Bell Type** and press **OK**.



Here you can select the bell type. If you want the ringtone to be played internally then select internal bell, for external select external bell and for both select internal and external bell.



Select **Ringtone** and press **OK**.



You can select any ringtone you want from the above options and press **OK**.




Select **Internal bell delay(s)** and press **OK**.


It specifies the duration for ringtone playing




You can edit the delay of the internal bell from the image above. It ranges from 5 to 99 seconds.



Select **All bell schedules** and press **OK**.




Select New Bell Schedule and press **OK**




Select **Edit** and press **OK**




Select Item you wish to edit.




Press ▼ to "Delete" and press **OK**.



Press ▼ to select **YES** or **NO**.




Press ▼ to select **Options** and press **OK**.



Select **External Bell Relay**.



Press ▼ to select, press **OK** to save and return.




5.4 PUNCH STATE OPTIONS


Press ▼ to select **Punch State Options** and press **OK**.



Press ▼|▲ and **OK** to select items. When the setting is completed, press **OK** to save the setting and exit.




The main interface displays the status keys that can be switched automatically, and you are also allowed to switch status keys manually. A status key you select manually will be switched according to the automatic switching plan after it disappears upon a timeout.




Punch state timeout specifies the timeout period of the status key displayed on the main interface.




You can change the punch state timeout from the image above. The timeout ranges from 5 to 99 sec.



specifies whether the status of work attendance check must be selected during authentication. Here when its off it won't be selected.



Specifies whether the status of work attendance check must be selected during authentication.
When it's on it will be selected.



5.5 SHORTCUT KEY MAPPING

Press ▼ to select **Shortcut Key Mappings** and press **OK**



Select the keys and assign the group to that key.



Pressing switch will enable and disable each individual "Job Group".



Select **F1** key as **Check-In**.



Select **Punch State Value** and press **OK**.

Here you can change the punch state value in the input screen by using the keypad. The value ranges from 0~250.


Here select punch state options as **Function**

You can change the function for the keys above.

Select name for F1

Choose the key you want for F1.

Select **Set Switch Time** and press **OK**.



Here you can **Switch Cycle**




Select job group and press **OK**. If you disable, the job group will be disabled and it will not show on the screen




You can select any job group you want and you can name the job group by using the keypad.



If you "Disable" the tip group the tip group will not be displayed on the screen.



To enable the tip group you can select the tip group you wish to enter in that group.



Here all the tip groups have been selected as above.

Shortcut Key Mappings	
ESC Key	Undefined
Up Key	Undefined
Down Key	Undefined
Right Key	Undefined
F1	Check-In
F2	Check-Out

Select **F2** as **Check-Out**.

F2	
Punch State Value	1
Function	Punch State Options
Name	Check-Out
Set Switch Time	
Select Job Group	Disable
Select Tip Group	Disable

Select **Punch State Value**.

F3	
Punch State Value	
Function	
Select Tip Group	

Select **F3** as "Tip code".

Here the punch state value is set to 251

For more details refer to paragraph 13.

Punch State Value

Please Input (0 ~ 254)

251

Confirm (OK) Cancel (ESC)

You can change the value of the punch state by changing the value in the input screen with the help of keypad.

F3	
Punch State Value	251
Function	Tip Code
Select Tip Group	Disable


Select **F3** as **Tip code**. For more details refer to No 13.

Function	
☐	Firmware Info
☐	Work Code
☐	Public Message
☐	Personal Record Search
☐	Job Code
☒	Tip Code


You can change the function for that key from the image above.



Here the tip group is disabled and no tip group has been selected.



You can select the tip group you want. Here all the tip groups are selected



When you select all the tip groups the select tip group will display as "All group".




Select **F4** as **Job Code**.


For More Details please refer to NO.12



Select the **Function** self-service for F4 and the F4 key will display as Job Code on the main screen.



You can change the functions from above.




5.6 MANUAL ADD LOG

Select manual add log and press **OK**.



Click on **User ID**



The user id is displaying as 1.



Click on **Verify mode.**



Here you can select any verification mode you want the user to get verified. The user can verify themselves either with their UserID, Fingerprint, Password or Card/Badge.



Select verify state as none. In this all the users from all states can verify themselves.
If you verify the state, the user from that state only can verify themselves.

Manual Add Log	
User ID	
Verify Mode	
Verify State	None
Date	11/03/17
Time	

Select **Date** and press **OK**.

Date		
11/03/17		
↑ 2017 ↓	↑ 11 ↓	↑ 03 ↓
YYYY	MM	DD
Confirm (OK)		Cancel (ESC)

You can set the date by using the keypad. Here the date is set to 11/03/2017.

Manual Add Log	
User ID	
Verify Mode	
Verify State	
Date	
Time	

Select **Time** and press **OK**.

Time			
12:43:38 PM			
↑ 12 ↓	↑ 43 ↓	↑ 38 ↓	↑ PM ↓
HH	MM	SS	
Confirm (OK)		Cancel (ESC)	

You can set the "Time" by using the keypad. Here the time is set to 12hr, 43min, 38ss.



DATA MANAGEMENT




Select **Data Manager** and press **OK**




6.1 DELETE DATA


Select **Delete Data** and press **OK**.



It will delete the attendance records



When selecting **Delete All** it will delete all the attendance records




You can delete the attendance data by **Time Range** too.




To selete by time range you can select the time you want the data to be deleted.


It will delete the data for that specific time you selected.



Here you can delete all data by selecting delete all data and press **OK**. **CANCEL** will take you back to previous screen.




Here you can delete admin role by selecting delete admin role and press **OK**. **CANCEL** will take you back to previous screen




6.2 BACKUP DATA


Press ▼ to select **Backup Data** and press **OK**.



Press ▼ to select **Backup to Device** and press **OK**.




Press ▼ and **OK** to select the local configuration items to be backed up to device.



You can select the content you want to backup.



Press ▼ to select **Backup Start** and press **OK**.



Backup to USB Disk, the operations are similar to those performed to Backup to Device.




If the usb is not properly inserted the above screen will be displayed. You can either change the USB or insert it properly again.




6.3 RESTORE DATA


Press ▼ to select **Restore Data** and press **OK**




Press ▼ to select **Backup from Device** and press **OK**



Select the local configuration items to be restored and save the selected items.




You can select the content you want to restore.



select **Start Restore** and press **OK**.

select **Yes** or **NO** Device and press **OK**.



Restore from USB Disk the operations are similar to those performed to restore from Device.




If the usb is not properly inserted the above screen will be displayed. You can either change the USB or insert it properly again.



ACCESS CONTROL



Select **Access Control** and press **OK**.




7.1 TIME SCHEDULE


Select "Time Schedule" and press **OK**.



Use numeric keys to search for a time period in the range from 1 to 50. Press **▼** to select the item to be set and press **OK**.




Press **/** to select a time option and press **▼** / **▲** to set time. After setting a period of time, press **OK** to save the setting and exit.



7.2 ACCESS GROUP

Select **Access Groups** and press **OK**.



Press **OK** to add **New Group**.

Access Groups	
No.	2
Verification Mode	Password/Fingerprint/Badge
Time Period 1	1
Time Period 2	0
Time Period 3	0
Include Holidays	☐ OFF

Press **OK**.

No.
Please Input (1 ~ 99)
2
Confirm (OK)
Cancel (ESC)

Enter the No. using the keypad and press **OK**.

Access Groups	
No.	2
Verification Mode	Password/Fingerprint/Badge
Time Period 1	1
Time Period 2	0
Time Period 3	0
Include Holidays	☐ OFF

Press ▼ to select **Verification Mode** and press **OK**.

Verification Mode	
☒	Password/Fingerprint/Badge
☐	Fingerprint only
☐	User ID only
☐	Password
☐	Badge only
☐	Fingerprint/Password

Select Verification Mode, press **OK** to save and return.

Access Groups	
No.	2
Verification Mode	Password/Fingerprint/Badge
Time Period 1	1
Time Period 2	0
Time Period 3	0
Include Holidays	☐ OFF

select **Time Period 1** and press **OK**

Time Period 1
Please Input (0 ~ 50)
1
Confirm (OK)
Cancel (ESC)

Enter the No. using the keypad and press **OK**

Access Groups

No.	2
Verification Mode	Password/Fingerprint/Badge
Time Period 1	1
Time Period 2	0
Time Period 3	0
Include Holidays	☐ OFF

Select Include Holidays, press **OK** to enable the item

Access Groups

New Group

All Groups

Select **All Groups** and press **OK**

All Groups

1	01 00 00
2	01 00 00

Search:

Select one of All Groups and press **OK**

Access Groups

Edit

Delete

Select **Edit** and press **OK**

Access Groups

No.	1
Verification Mode	Password/Fingerprint/Badge
Time Period 1	1
Time Period 2	0
Time Period 3	0
Include Holidays	☐ OFF


The No. cannot be modified, and the other operations are similar to those performed to add a New Groups Press "ESC" to return

Access Groups

Edit

Delete

select **Delete** and press **OK**



If you select **OK** it will delete all the access groups and when you select **Cancel** it will take you to the previous screen without deleting any access groups.



USB MANAGER




Go to Menu and select USB Manager and press **OK**.




8.1 DOWNLOAD

Select **Download** and press **OK**.




Select the items you want to download.


Here when we select the **Attendance Data** it will import all the attendance data from the FFR terminal to USB disk




User data will import all the user information, fingerprints and facial images from the FFR terminal to a USB disk



User Portrait will Import the employees' photos from the terminal to a USB disk.



Work code will save the work IDs on the device to a USB drive



The short message will be displayed by the administrator and will be imported from terminal to USB disk.



8.2 UPLOAD


Select **Upload** and press **OK**.

In Upload it will upload all the data from USB disk to terminal.




Screen saver will Upload the JPG documents with "ad_" as initial letters of document names stored in a USB disk to the terminal. After the upload, these pictures can be displayed on the initial interface of the terminal.

See page 62 for detailed instructions




8.3 DOWNLOAD OPTIONS


Select **Download Options** and press **OK**.




Press **▼** and **OK** to select items. When the setting is completed, press **OK** to save the setting and exit.



This will download all the encrypted attendance data of the employee.



If the **ATT data** is **OFF** it won't download any data as the function is disabled.



If the **ATT data** is **ON** it will download the data as the function is enabled.



Instructions for Uploading Wallpapers and Screensavers Via USB Pen Drive

PREREQUISITES: **Supported File Extensions:** bmp, jpg, png | **Image File Size:** No larger than 200 KB | **Resolution Sizes:** 400 x240 pixel

Wallpaper:

1. Created a folder in the root of the USB drive labeled **wallpaper**
2. Place the desired wallpapers inside this folder. Make sure to follow the supported file types and sizes.
3. The filename for each image should be followed as the image below:

Name	Size	Type
wallpaper9.jpg	38 KB	JPG File
wallpaper10.jpg	43 KB	JPG File
wallpaper11.jpg	12 KB	JPG File
wallpaper12.jpg	80 KB	JPG File
wallpaper13.jpg	43 KB	JPG File

Make sure to start from **wallpaper9.jpg** to avoid overwriting existing wallpaper images

4. Insert USB drive to device and navigate to USB Manager>Upload>Wallpaper.
5. Select the images you wish to upload or upload all the pictures at once.

Screen Saver:

1. Created a folder in the root of the USB drive labeled **advertise**
2. Place the desired screen savers inside this folder. Make sure to follow the supported file types and sizes.
3. The filename for each image should be followed as the image below:

Name	Size	Type
ad_pic9.jpg	38 KB	JPG File
ad_pic10.jpg	43 KB	JPG File
ad_pic11.jpg	12 KB	JPG File
ad_pic12.jpg	80 KB	JPG File
ad_pic13.jpg	43 KB	JPG File

Make sure to start from **ad_pic9.jpg** to avoid overwriting existing screensaver images

4. Insert USB drive to device and navigate to USB Manager>Upload>Screen Savers.
5. Select the images you wish to upload or upload all the pictures at once.




ATTENDANCE SEARCH


ATTENDANCE SEARCH



Go to menu and select **Attendance Search** and press **OK**.



Enter the ID you want to view the data for in the input section by using the keypad and press **OK**.



Enter the **User ID** then press **OK**.




After you enter the ID it will give you options to view the attendance records for today or other weeks.


Date	User ID	Attendance
12-11		Number of Records:02
	1	15:37 15:37

Navigation instructions at the bottom: Prev : Left key Next : Right key Details : OK

The records in accordance with the conditions will be displayed as above.



Enter the other ID you want to view for the attendance record.



If the ID is not valid there will be no record and it will show as no enrolled data as shown above.



SHORT MESSAGE




Go to Menu and select **Short Message** and press **OK**.




10.1 NEW MESSAGE


Click on **New Message** and press **OK**



Click on the **Message** option as shown above.



After you click on "Message" the above screen will appear in which you can type the message you wish to send with the help of the keypad.



Click on **Start Date** and press **OK**.



Here you can edit the date you wish the message to be displayed.

New Message	
Message	
Start Date	02-08-18
Start Time	11:50 AM
Expired Time (m)	60
Message Type	Draft

Click on **Start Time** and press **OK**

Start Time		
11:50 AM		
↑ 11 ↓	↑ 50 ↓	↑ AM ↓
HH	MM	
Confirm (OK)		Cancel (ESC)

Here you can edit the "Start Time" to what time you want the message to be displayed.

New Message	
Message	
Start Date	02-08-18
Start Time	11:50 AM
Expired Time (m)	60
Message Type	Draft

Click on **Expired Time** and press "OK".

Expired Time (m)	
☐	Never Expire
☐	30
☒	60
☐	90
☐	120
☐	User Defined

Here you can choose the time you want the message to be expired from the screen.

The "Expired Time" ranges in minutes.

New Message	
Message	
Start Date	02-08-18
Start Time	11:50 AM
Expired Time (m)	60
Message Type	Draft

Click on "Message Type" and press "OK".

Message Type	
☐	Public
☐	Personal
☒	Draft

From the menu above you can select the "Message Type" you wish to display.



Go to Menu and select **Short Message** and press **OK**.



10.2 PUBLIC MESSAGES

Select **Public Message** and press **OK**.




The message will be displayed on the screen as above.




10.3 PERSONAL MESSAGES

Here also if you want to view any Personal Message click on **Personal Message** and press **OK**.




10.4 DRAFT MESSAGES

Select **Draft Messages** and press **OK**.




The draft messages will be displayed as above.




10.5 MESSAGE OPTIONS

Select **Message Options** and press **OK**



Press **OK**.



Select the **Time** and press **OK**.



WORK CODE




Go to menu and select **Work Code** and press **OK**.




11.1 NEW WORK CODE

Select **New Work Code** and press **OK**.




Select **ID** and Press **OK**



Enter the user ID using keypad, press **OK**.



Select **Name** and press **OK**




Enter the name then press **OK**.




11.2 ALL WORK CODES

Select **All work codes** and press **OK**.



View **All work codes**.




Press ▼ to select the one you want to edit or delete.

In edit you can edit the information and delete will delete the work code for that ID.




11.3 SET WORK CODE


Select **Work code options** and press **OK**.



When the work code required is **OFF** it will disable the required work code.




Select **ON** for workcode required.



When you turn **ON** the workcode required it will ask you to set the timeout for the input screen.

Click on input screen timeout.




Here you can change the timeout for the input screen from the image above.

The timeout is in seconds.



When you select **OFF** for the function above, the work code will not be defined and will be disabled.



When you select **ON**, the work code will be defined and it will enable that function.



JOB CODE



Go to menu and select **Job code** icon.



12.1 NEW JOB CODE


Select **New Job Code**




Select Job Group ID and then assign a particular job code from the category such as **Country** as shown above.



Select **Country**. The job group id will be selected as country.



Select **Job Code ID**



Enter Job Code ID or edit Job ID to represent the job code such as NO. 1 as shown above.

Job Group ID	Country	Job Code ID	Job Code Name
		1	

Select **Job Code Name**.

Input the **Job Code Name** in the box above. With the help of keypad you can input the name.

Enter the job code name **USA** as shown above

Job Group ID	Country	Job Code ID	Job Code Name
		1	USA

All input information you enter will be displayed on the screen as above. Press "ESC" button to go back to last menu and it will save all the information you entered

12.2 ALL JOB CODE

Go to menu and select **Job Code**

Select **All JOB codes**.

Select Job Group

- ☒ Country
- ☐ State
- ☐ City
- ☐ Block
- ☐ Street
- ☐ Zip

Select **Country**

All Job Codes

1	USA
2	UK
3	Mexico
4	Canada

There is only one job code "USA" assigned in to this group" Country 1

Select Job Group

- ☐ Country
- ☒ State
- ☐ City
- ☐ Block
- ☐ Street
- ☐ Zip

Select **State**

All Job Codes

61	Greater Manchester
201	New Jersey
202	Washington
212	New York
312	Illinois
606	Hawaii

After selecting state, it will display all the job codes assigned to different states as shown above.

Select **Greater Manchester** as shown above to select the particular state

Select Job Group

- ☐ Country
- ☐ State
- ☒ City
- ☐ Block
- ☐ Street
- ☐ Zip

Select **CITY**

All Job Codes

1	Honolulu
2	Chicago
3	Manchester
28	Mexico City
201	Jersey City
978	Piscataway

After selecting CITY all the job codes will be displayed according to the city as shown above and you can select whichever is applicable to you.

Select Job Group

☒ Country

☐ State

☐ City

☐ Block

☐ Street

☐ Zip

Select **BLOCK**

All Job Codes

1	1st block
2	8th block
3	5th block
4	101 block

The different blocks will appear.

Select 1st block as shown above to select the particular block

Select Job Group

☒ Country

☐ State

☐ City

☐ Block

☐ Street

Select **Street**

All Job Codes

1	Market Street
2	West Main Street
3	East Street
4	Sepulveda Blvd
5	Demarino Road

The different Streets will appear as shown above.

Select Market street as shown above to select the particular street

Select Job Group

☒ Country

☐ State

☐ City

☐ Block

☐ Street

☐ Zip

Select **ZIP**

All Job Codes

1	08854
2	08858
3	07097
4	07101
5	91740
6	90249

The different ZIP codes will appear as shown above.

Select ZIP Code 08854 as shown above to select the job code for that zip code.



Go to menu and select **Job Code**



12.2 ALL JOB CODES

Select **All Job codes** .




Select **Country**

1	USA
2	UK
3	Mexico
4	Canada

The job codes assigned to different countries will be displayed as shown above. Select **1 USA** for the particular job code for that country.



After selecting 1 USA click on the **Edit** function.



Click on the **Job code ID** if you want to edit the id number from 1 to a different number.

Edit	
Job Code ID	1
Job Code Name	USA

Click on **Job Code Name** to edit the name for that job code

Job Code Name

Please Input

USA

[Aa]

Enter the **Job code Name** by using the keypad.

Job Code Name

Please Input

America

[Aa]

Change the name from "USA" to America

Job Code Name

Please Input

America

Confirm (OK) Cancel (ESC)

Click on confirm **OK** button to select America.

Edit	
Job Code ID	1
Job Code Name	America

The job code name will change to America as shown above.

All Job Codes	
1	America
2	UK
3	Mexico
4	Canada

When you select all job codes, America will be displayed in job code ID 1 as shown above.



To delete the job codes in the particular group
Go to menu and select **Job Code**.



Select **All Job Codes**



Select **Country** as shown above




Select the job code you wish to delete.
Here select **USA**.



Click on the **Edit** function to change the name of the group.




When you select **Delete** it will delete the particular group you want to delete



When you press **Delete** the above screen will be displayed.

When you press **NO** to execute it will go back to last menu screen and nothing will be edited or deleted



When you press delete the above screen will be displayed.

When you press **YES** to execute it will execute the function and delete the particular job group you selected.



Group name USA is deleted and the other groups remain as shown above.



Job Code Options_Menu_Operation

Go to menu and select **Job Code** icon.



Job Code Options_Menu_Operation

Go to menu and select **Job Code** icon.



12.3 JOB CODE OPTIONS

Select **Job Code Options**.



Turn **ON** the **Job Code Required** function to enable, and **OFF** to disable. Input Screen Timeout is used to set up the time period for displaying the job code list in seconds.

Switch **Job Code Must Defined** to force a job code to be selected before verification.



When you turn **OFF** the job code required function it will disable that function.


When you turn **ON** the job code must defined it will enable the function.




Select Input Screen Timeout as shown above.




Select the time you want the screen to go idle. In this case 5 seconds is selected. when you select 5 seconds the screen will go to idle state if no registration or activity is performed on the clock.



Select user defined function as shown above to set your own time for input screen timeout.




After selecting user defined function, the screen above will allow you to input the time.



Here we put 15 seconds and then click on confirm **OK** function to get that time selected.



After pressing confirm **OK** function the image will be displayed as above.



Turning **ON** **Job Code Required** will enable that function.
Switch "Job Code Must Defined" to **ON** to force a job code to be selected before verification
The input screen timeout for job code is selected as 15 seconds as shown above.



Switching **Job Code Must Defined** to **OFF** will not force a job code to be selected before verification



12.4 JOB GROUP OPTION MENU OPERATION


Go to menu and select **Job code**



Select **Job Group options**.




Use **ON** or **OFF** to enable / disable the each individual **Job Groups**.




The name of the group can be edited by selecting **Set Job Group Name** individually.


To set a Job Group Name click on set job group name as shown above.



This screen will appear when you press the set job group name.



To change the job group name to country as shown above we need to press* key to switch the input method and type country using the keypad. After that press confirm **OK** button.



After you press confirm **OK** button the set group name will change from undefined 1 to Country as shown above.




Similar way you can put the different job group name as shown above. Group1>> Country, group 2>> State Group3>> City.




Select the job group you want to enable by pressing the **ON** function. Other groups with **OFF** function selected will be disabled. The job code functions will be active only to the group which is enabled **ON**.



To change the group name select Set Job Group name.



Change the current group name country by pressing* key on the keypad of the clock



Change the group name to Nation as shown above.



The group name will be changed to Nation as shown above.



TIP CODE




Go to menu and select Tip Code and press **OK**.




If you press **ON** it will enable that tip code function.

If you press **OFF** it will disable that tip code function

Here Tip group 1 is enabled and Tip Groups 2 and 3 are disabled.




To set the tip group name select **Set Tip Group Name**.




13.1 TIP CODE SETTINGS

Switch **Enable All Tip Group** to **ON** to enable Tip Code function; **OFF** to disable Tip Code function.


The groups can be turned on/off individually using **ON** or **OFF** associated with each tip group



If you switch **ON** to enable all tip group it will disable all the tip group and no tip groups will be shown as above.




When you select the set tip group name the following image will be displayed and you can edit the name of the group from breakfast to other name by pressing* key on the keypad and # key for space



Here the Tip group is being changed from breakfast to Dinner with the keypad on the clock.



After you change the name press Confirm **OK**




Once you hit the Confirm **OK** button the set tip group name will be changed to Dinner as shown above.



13.2 TIP CODE


Go to menu and select "Personalize" and press **OK**.



Select **Shortcut key mappings** and press **OK**.




Select **F3** as tip code.




In F3 Select Punch State Value.




You can change the punch state value by editing in the input section using the keypad.




Select **Function**




In function key select **TIP code**.




Here you can enable or disable **Select Tip Group** function.



If the check mark is not selected on the box no tip group will be selected and it will be disabled as above




If you check mark all the groups as above all the Tip Groups will be enabled.



If all three tips are selected, **Select Tip Group** will be displayed as **All Group**.




Select F3 key on the main screen as tip code.




You can edit the tip in the amount of dollars by pressing up and down arrow on the keypad according to group.

Here for breakfast tip is set to 8 dollars and then press confirm **OK**.



You can edit the tip in the amount of dollars by pressing up and down arrow on the keypad according to group.

Here for Lunch tip is set to 12 dollars and then press confirm **OK**.



You can edit the tip in the amount of dollars by pressing up and down arrow on the keypad according to group.

Here for Supper tip is set to 18 dollars and then press confirm **OK**.



Once all the tips are set according to the group the user from the group can easily punch in and punch out by their fingerprint and the above image will be displayed if the fingerprint is successfully verified.



AUTOTEST




Go to menu and select "Auto test" and press **OK**.



14.1 ALL TEST

Select **Test All**.

The terminal automatically tests the LCD, voice, sensor, keyboard and clock, press **OK** to continue and press **[ESC]** to exit



14.2 TEST LCD


The terminal automatically tests the display effect of the color TFT display by displaying full color, pure white and pure black and checks whether the screen displays properly.




You can continue the test by touching the screen or exit it by pressing **[ESC]**



The terminal automatically tests the display effect of the color TFT display by pure black




Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press **ESC**




Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press ESC



Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press ESC



Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press ESC




Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press ESC



Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press ESC




Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press ESC



14.3 TEST VOICE

Here you can test the different voice wav file. To continue the voice test press **OK** and to exit press **ESC**



14.5 TEST FINGERPRINT SENSOR

The terminal automatically tests whether the fingerprint collector works properly by checking whether the fingerprint images are clear and acceptable. When the user places his/her finger in the fingered guide, the collected fingerprint image is displayed on the screen in real-time. Press **[ESC]** to exit the test



14.4 TEST KEYBOARD

The terminal tests whether every key on the keyboard works normally. Press any key on the [Keyboard Test] interface to check whether the pressed key matches the key displayed on screen. The keys are dark-gray before pressed, and turn blue after pressed. Press **[ESC]** to exit the test.



14.6 TEST CLOCK RTC

Test Clock RTC: The terminal tests whether its clock works properly by checking the stopwatch of the clock. Touch the screen to start counting, and touch it again to stop to check whether the counting is accurate. Press **[ESC]** to exit the test.



SYSTEM INFORMATION



Go to menu and select **System Info** and press **OK**.



15.1 DEVICE CAPACITY

Select **Device Capacity**

Device Capacity	
User (used/max)	1/10000
Admin User	0
Password	1
Fingerprint (used/max)	1/3000
Badge (used/max)	1/10000
ATT Record (used/max)	4/50000

The number of enrolled users, administrators, passwords, the total fingerprint storage capacity and occupied capacity, ID cards and attendance capacity are displayed respectively

Device Capacity	
Admin User	0
Password	1
Fingerprint (used/max)	1/3000
Badge (used/max)	1/10000
ATT Record (used/max)	4/50000
User Photo(used/max)	0/2000

The number of enrolled users, administrators, passwords, the total fingerprint storage capacity and occupied capacity, ID cards and attendance capacity are displayed respectively



15.2 DEVICE INFO

Click on "Device info" and press **OK**.

Device Info	
Device Name	US15C-ID
Serial Number	8895172400009
MAC Address	00:17:51:12:92:52
Fingerprint Algorithm	Finger VX10.0
Platform Information	ZMM200_TFT
MCU Version	24

The Device name, serial number, MAC Address, Fingerprint Algorithm, platform information and MCU version are displayed on device interface.

Device Info	
MAC Address	00:17:61:12:82:52
Fingerprint Algorithm	Finger VX10.0
Platform Information	ZMM200_TFT
MCU Version	24
Manufacturer	ZK Tech
Manufacture Date	07/31/2017 01:09:15

Manufacturer and Manufacture date are displayed on the device interface

System Info	
	Device Capacity
	Device Info
	Firmware Info

15.3 FIRMWARE INFO

Click on **Firmware Info** and press **OK**.

Firmware Info	
Firmware Version	Ver 8.0
Bio Service	Ver 2.1.12-2
Push Service	Ver 2.0.24S-2
Standalone Service	Ver 2.1.0-2
Dev Service	Ver 1.0.101-2

The Firmware version, Bio Service, Push Service, Standalone Service, Dev Service and System Version are displayed on the firmware info interface

