

Quick Start Guide for the Self-Service Attendance Terminal Version: 4.1



1. Department Setting (Not Required If the Default Department Is Selected)

1. Press and hold the [M/OK] key to enter the Main menu. Choose Dept. Set and press the [M/OK] key to the Department Set interface:



2. Press ▼ to select the department and press the [M/OK] key to enter the modification interface.

3. Press the '3' key to enter the **Add department** interface, input the department name by using the T9 input method (for details, see page 4), and press the [**M/OK**] key to save the setting.



2. User Registration

1. Press and hold the [M/OK] key to enter the Main menu. Press key to select User Mgt. -->
Add User and press [M/OK] key to enter the Add User interface:



ID: Enter an employee ID.

Name: Enter a name by using the T9 input.

FP: Press the [**M/OK**] key to enter the Enroll fingerprint interface, press against the fingerprint collector three times with the same finger.

PWD: Enter a password that consists of 1 to 8 digits.

Dept.: Press **b** to select a department from the list.

Purview: Press to select user permission from the list. An administrator can be registered.



3. Attendance Rule Setting (Not Required If you use the Default Rule.

1. Press and hold the [M/OK] key to enter the Main menu. Press key to select Shit set --> Attendance Rule and press [M/OK] key to enter the Attendance Rule interface:

Note: Schedule Type can be set to Dept. Shifting or Personal Shifting. The default shift is applied to departments or employees without shift schedules.



Press ▲/▼ to move the cursor to a desired option.
Enter a desired value in the entry box using the
numeric keypad. Press ▼/▶ key in the scroll box to
switch to the desired value. After finishing the setting,
press [M/OK] to save your settings or press [ESC] to
cancel your settings and return to the previous
interface.



4. Shift Setting (Not Required If the Default Shift Is Selected)

1. Press and hold the [M/OK] key to enter the Main menu. Press key to select Shit set -->
Shift Setting and press [M/OK] key to enter the Shift Setting interface:





Shift 1: From 09:00 to 18:00, with attendance required twice a day.

Shift 2: From 09:00 to 12:00 in the morning and from 13:00 to 18:00 in the afternoon, with attendance required four times a day. Other shifts can be set as required.

2. Press \triangle/∇ to move the cursor to the parameter that you want to set, enter the shift name by using the T9 input method, and enter the on-duty and off-duty time by using the numeric keys.



5. Schedule Setting (Not Required If the Default Schedule Is Selected)

Press and hold the [M/OK] key to enter the Main menu. Press key to select Shit set --> Schedule Setting and press [M/OK] key to enter the Schedule Setting interface:

When Dept. Shifting is selected for Attendance Rule:




Press ▼ to select shift then press [M/OK] key to enter the Edit Schedule interface.



Press ▼ key to select **Shift Name**. Press [**M/OK**] key to save.

When Personal Shifting is selected for Attendance Rule:

2



The default shift is applied to employees without shift schedules.



6. Employee Attendance

Within the specified attendance time, an employee presses against the fingerprint collector with the finger used for registration or uses a password for attendance.




7. Download and Report Check

FREE

1. Press and hold the [M/OK] key to enter the Main menu. Press ▶ key to select Report -->

Download Att. Report and press [M/OK] key to enter the Download TZ setting report




& downloading.



Appendix 1 T9 Input Method Description

The T9 input method is used to enter texts such as employee names, department names, and shift names.





Appendix 2 Quick Search for Employee Attendance Records

Press the '0' key when the initial interface is displayed. Press numeric key to enter the **ID.**

 $\qquad \qquad \Box \rangle$

Enter the record time by using the numeric keys and press the [M/OK] key. The records are displayed.



Contact information:

Southern regions: 400-8840-880 (09:00–18:00 from Monday to Saturday)

Northern regions: 400-7000-500

All functions are subject to the actual products. **ZKTeco** is not liable for the inconsistency between this document and actual products due to constant update of the products or any discrepancy caused by the inconsistency between this document and actual technical parameters. This document may be updated without prior notification.

For more information, see the **Self-Service Attendance Terminal User Manual**, which can be downloaded from www.zkteco.com.