# Network Bullet Cameras Quick Guide

Manual Version: V1.01

Thank you for purchasing our product. If there are any questions, or requests, please do not hesitate to contact the dealer.

# Copyright

Copyright 2015 Zhejiang Uniview Technologies Co., Ltd. All rights reserved. No part of this manual may be copied, reproduced, translated, or distributed in any form or by any means without prior consent in writing from our company.

# Trademark Acknowledgement

and other Uniview's trademarks and logos are the property of Zhejiang Uniview Technologies Co., Ltd. Other trademarks, company names and product names contained in this manual are the property of their respective owners.

### Disclaimer



The default password is used for your first login. To ensure account security, please change the password after your first login. You are recommended to set a strong password (no less than eight characters).

- To the maximum extent permitted by applicable law, the product described, with its hardware, software, firmware and documents, is provided on an "as is" basis.
- Best effort has been made to verify the integrity and correctness of the contents in this manual, but no statement, information, or recommendation in this manual shall constitute formal guarantee of any kind, expressed or implied. We shall not be held responsible for any technical or typographical errors in this manual. The contents of this manual are subject to

- change without prior notice. Update will be added to the new version of this manual.
- Use of this manual and product and the subsequent result shall be entirely on your own responsibility. In no event shall we be reliable to you for any special, consequential, incidental, or indirect damages, including,
  - incidental, or indirect damages, including, among others, damages for loss of business profits, business interruption, or loss of data or documentation, or product malfunction or information leakage caused by cyber attack, hacking or virus in connection with the use of this product.
- Video and audio surveillance can be regulated by laws that vary from country to country. Check the law in your local region before using this product for surveillance purposes. We shall not be held responsible

for any consequences resulting from illegal operations of the device.

- The illustrations in this manual are for reference only and may vary depending on the version or model. As a result, some of the examples and functions featured may differ from those displayed on your monitor.
- This manual is a guide for multiple product models and so it is not intended for any specific product.
- Due to uncertainties such as physical environment, discrepancy may exist between the actual values and reference values provided in this manual. The ultimate right to interpretation resides in our company.

### **Environmental Protection**

This product has been designed to comply with the requirements on environmental protection. For the

proper storage, use and disposal of this product, national laws and regulations must be observed.

# Safety and Compliance Information Safety Symbols

The symbols in the following table may be found on installation-related equipment. Be aware of the situations indicated and take necessary safety precautions during equipment installation and maintenance.

Symbol	Description	
<u>į</u>	Generic alarm symbol: To suggest a general safety concern.	
ESD protection symbol: To suggest electrostatic-sensitive equipment.		
4	Electric shock symbol: To suggest a danger of high voltage.	

The symbols in the following table may be found in this manual. Carefully follow the instructions

indicated by the symbols to avoid hazardous situations and use the product properly.

Symbol	Description	
<u> </u>	warning! Indicates a hazardous situation which, if not avoided, could result in bodily injury or death.	
CAUTION! Indicates a situation which, if not avoided, could result in damage, dat loss or malfunction to product.  NOTE! Indicates useful or supplemental information about the use of product.		

### Safety Information

Installation and removal of the unit and its accessories must be carried out by qualified personnel. Please read all of the safety instructions below before installation and operation.

#### Installation

- This device is a class A product and may cause radio interference. Take measures if necessary.
- Make sure the power supply voltage is correct before using the camera.
- Do not drop the camera or subject it to physical shock.
  - Do not touch sensor modules with fingers. If cleaning is necessary, use a clean cloth with a bit of ethanol and wipe it gently. If the camera will not be used for an extended period of time, put on the lens cap to protect the sensor from dirt.
  - Do not aim the camera lens at the strong light such as sun or incandescent lamp. The strong light can cause fatal damage to the camera.

- The sensor may be burned out by a laser beam, so when any laser equipment is being used, make sure that the surface of the sensor not be exposed to the laser beam.
- While shipping, the camera should be packed in its original packing.

### Maintenance

- If there is dust on the front glass surface, remove the dust gently using an oil-free brush or a rubber dust blowing ball.
  - If there is grease or a dust stain on the front glass surface, clean the glass surface gently from the center outward using anti-static gloves or an oil-free cloth. If the grease or the stain still cannot be removed, use anti-static gloves or an oil-free cloth dipped with detergent and clean the glass surface gently until it is removed.

 Do not use organic solvents, such as benzene or ethanol when cleaning the front glass surface.





- Never look at the transmit laser while the power is on. Never look directly at the fiber ports and the fiber cable ends when they are powered on.
- Use of controls or adjustments to the performance or procedures other than those specified herein may result in hazardous laser emissions.

# **Regulatory Compliance**

#### FCC Part 15

This equipment has been tested and found to comply with the limits for digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may interference cause harmful tο radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

This product complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference
- This device must accept any interference received, including interference that may cause undesired operation.

### LVD/EMC Directive



This product complies with the European Low Voltage Directive 2006/95/EC and EMC Directive 2004/108/EC.

### WEEE Directive-2002/96/EC



The product this manual refers to is covered by the Waste Electrical & Electronic Equipment (WEEE) Directive and must be disposed of in a responsible manner.

# **Contents**

1	Packing List
2	Appearance2
	Dimensions and Appearance2
	Cable Connection2
3	Mount Your Camera3
	Wall Mount3
	Start Your Camera6
	Waterproof Components for an RJ45 Plug7
	Waterproof Tail Cable8
4	Set Your Camera over the LAN10
5	Access Your Camera12
	Access Your Camera 12

Install the ActiveX	1	3
---------------------	---	---


# 1 Packing List

No.	Item	Quantity
1	Camera	1
2	User document	1
3	Accessory pack	1

Contact your local dealer if the package is damaged or incomplete.

# 2 Appearance

# **Dimensions and Appearance**



# **Cable Connection**



Description	No.	Description
RESET button	0	Earth terminal
Power interface	4	Network interface
	RESET button	RESET button



- For specifications, see the latest product datasheets
- Press and hold the RESET button for at least 15 seconds to restore factory default settings. Perform this operation within 10 minutes after the device is powered on or the reset will fail otherwise.

### 3 Mount Your Camera

### Wall Mount

You can adopt wall mount or ceiling mount and purchase hardware accessories by yourself. The

following part takes wall mount as an example. Ceiling mount is similar to wall mount and therefore is omitted here.

- Locate the positions
   of the holes
  - Paste installation positioning stickers on the wall and align the cross center to the hole in the wall.
- Lead the cables across the hole on the wall.
- 3 Mount the plastic rivets of self-tapping screws.





- Drill holes on the wall.
  - ① Use a Ø6-6.5mm drill bit.
  - Drill 30 mm-depth guide holes according to the positions marked by stickers.
- 4 Screw the locknut to loosen the universal joint before attaching your camera to the wall.



5 Mount your camera onto the wall and connect all cables.



Lead tapping screws through the guide holes in the base and fix them on the wall by using a screwdriver.

7 Power on your camera and adjust images. 6 Adjust the monitoring direction.



- Adjust the opening of the universal joints as required.
- Rotate the spherical hinge of the camera to get the desired monitoring direction.
- Tighten the locknut.

The preceding installation process is for concealed installation, during which holes are punched on the wall and cables are penetrated into the wall. If open installation is adopted, cables are not penetrated into the wall but threaded out from the outlet on one side of the base.

#### Start Your Camera

After verifying that your camera is properly mounted, connect the power cable to it and the other end of the cable to the mains. Then start your camera.

# Waterproof Components for an RJ45 Plug

1 Attach the seal ring to the waterproof connector.



3 Insert the cylindrical waterproof ring into bolt.



5 Screw in the waterproof bolt lid.



2 Mount the waterproof components.



4 Insert the cable into the connector and screw the waterproof bolt in



6 Finish the waterproof installation.





In step 2, you can crimp the inner wires of the cable with the RI45 plug first and then cover the waterproof components. You may also cover the waterproof components first.

## Waterproof Tail Cable

Connect the tail cables and then take the following steps to protect the tail cables from water using waterproof tapes. The figures are only for illustration purpose.

- Connect the tail cables.
- 2 Protect the connected cables using insulating tapes.



3 Protect other cables using insulating tapes.



5 Choose a start point for waterproof tapes.



4 Wrap all the tail cables together using insulating tapes.



6 Protect the tail cables using waterproof tapes.





- Avoid short circuit when insulating the cables.
- Use self adhesive waterproof tapes that will stick together with the twisted cables.
- Tighten waterproof tapes when wrapping the cables and make sure the cable connections are fully covered.
- You are recommended to put the waterproof cables in a waterproof junction box which needs to be purchased separately.

### 4 Set Your Camera over the LAN

To view and configure your camera via the LAN (Local Area Network), you need to install the EZStation to find your camera and change its IP address.



- Please contact your dealer to get the FZStation
- Please refer to the user manual of EZStation for detailed information.
- Connect your camera and your PC as shown in the figure below to ensure the routing is available.



- Use EZStation to search online cameras automatically.
- Modify your camera settings if necessary, including its IP address and subnet mask.



- The default IP address is "192.168.0.13". The default username is "admin" and the default password is "123456".
- To access your camera from a different subnet, set the gateway for your camera after you log in.

### 5 Access Your Camera

#### Access Your Camera

Before you begin, check that:

- Your camera is operating properly and connected to the network.
- The PC you are using is installed with Internet Explorer 7.0 or later. IE 8.0 is recommended.

Follow these steps to access your camera through the Web interface:

- Open your browser, input the IP address of your camera (default IP is 192.168.0.13) in the address bar and then press Enter to open the login page.
- Enter the username (default is "admin") and password (default is "123456") and then click Login.
  - Install the ActiveX at your first login. For the detailed steps, see <a href="Install the ActiveX">Install the ActiveX</a>. When the installation of the ActiveX is completed, open your IE to log in.

### Install the ActiveX

The following takes the IE browser as an example to describe the installation steps.

### 1. Click Download.



- Click Run to install the downloaded ActiveX. You may also click Save to download the file to your computer first.
- Close the browser and follow the steps to complete the installation.



- For your first login with Windows 7, if the system does not prompt you to install ActiveX, follow these steps to turn off UAC: click the Start button, and then click Control Panel. In the search box, type uac, and then click Change User Account Control Settings. Move the slider to the Never Notify position, and then click OK. After UAC is turned off, log in again.
- If the installation failed, open Internet Option in IE before login. Click the Security tab, click Trusted sites, and then click Sites to add the website. If you use Windows 7, you need to save the setup.exe to your PC first, and then right-click the file, select Run as administrator, and then install it according to instructions.

BOM: 3101C0C5